

How to Install – Easy, Quick Start Steps

1.) Pre-wire Keypads

- Use CAT-5 network cable for wiring to in-wall keypads, provided with this Elevate system.
- Terminate CAT-5 wire with modular RJ-45 connector on both ends. A terminated length of CAT-5 will be need for each room.
- One end plugs into back of keypad in each room (keypads provided). The other end plugs into back of Allport Connection (also included).

2.) Pre-wire Speakers

- 2 runs of 16 gauge, 2 conductor speaker wire is needed for each room. Use in-wall rated speaker wire.
- At each speaker terminate the red conductor for the positive signal and the black conductor for the negative signal at the back of the speaker.
- The wiring coming from each room is terminated at the appropriately labeled connector at the back of the Allport.

3.) Installing to Allport Multi-connection Hub

- Affix the 25 pin Allport cable included with the Elevate system into the 25 pin Allport wall termination hub.
- The other end of the Allport cable terminates at the 25 pin connection on the back of the Elevate Amplifier.

4.) Installing the main amplifier unit

- The main amplifier unit should be co-located with your provided audio source equipment.
- Use standard RCA cables for connecting the left and right audio signals from the audio source equipment to the Elevate main amplifier component.